



Degreaser Plus

High performance degreaser penetrates tough grease, lifting it from the surface.
For use on grills, ovens and hard surfaces in the kitchen area.



Two in one cleaner
and degreaser



Outstanding
performance



Full strength action
destroys toughest
grease build up



Easy and simple
to use



Fast acting & high
performing formula,
dissolves greasy
soils



Economical use



Effective grease
remove



Color coded labelling

Use Instructions:

- Wear protective gloves and goggles while using TOPCLIN Degreaser Plus.
- Turn off oven and grill or other appliances to be cleaned.
- The temp. should be lower than 50 °C.
- Spray TOPCLIN Degreaser Plus on the surface to be cleaned.
- Allow the product to penetrate grease deposits for 5 to 10 minutes.
- Wipe off dissolved and loosened grease with a damp cloth or paper.
- Rinse surface with plenty of clean water.

Safety Information:

Carefully read the Safety Data Sheet (SDS) before using this product.

Scan the QR Code to find more information



PACK SIZE

SKU CODE

2 X 5 L
12 X 1 L

25640/7106434
25639/7106433

Contact your local Ecolab Representative

Ecolab MEA Headquarters
PO Box 262015 Dubai
United Arab Emirates

ECOLAB Tem. Sis. Ltd. Şti.
Vizyon Bulvarı, No: 13/65
34870 Kartal / Istanbul

ECOLAB South Africa
1 Ampere Street, Chloorkop
Edden Glen 1613
Johannesburg South Africa

Ecolab Egypt
Postal Code 11835
Cairo Egypt